



3D CERAMIC COATING INSTRUCTIONS

Part # 935CC-Kit

- Before applying the Ceramic Coating, it is important to have the surface completely clean and decontaminated. (Paint correction process is recommended.)

- When surface is ready, wipe down using a surface cleaner to remove all residues and polishing oils. You may repeat this step if necessary.

Application:

1. Wrap the 3D Suede Applicator around the 3D Block and apply enough coating to cover the flat surface of the suede.
2. Using a cross hatch pattern (side to side then up and down strokes), spread the coating evenly. Work in sections.
Important: Weather will determine the size of the section you want to work with. Temperature and humidity can affect how quickly the product dries. Apply more product if the suede dries up.
3. Wait **30 seconds** and buff the product off with a clean, soft microfiber towel. If surface feels oily after buffing, wait a few more seconds and wipe off again.

Note:

For more protection, a second coat is recommended. Wait between 30 to 45 minutes after the first application and repeat the whole process. In this second step, wait 30 seconds, and then remove the product with a new and clean microfiber towel.

Tips and Recommendations:

- Make sure surface is well prepped and free of any oils and residues.
- Apply the product in small sections so the product does not dry on the surface.
- To ensure a proper curing process, do not wash the surface for **72 hours** after finishing the application. To achieve the optimum results, it is safe to wash the car **5 days** after application.
- Do not leave the bottle open at any time during the application process.
- Be advised that this instruction sheet will guide you through the application process; the removal time may vary depending on the weather conditions.
- It is highly recommended that you apply the product in a closed area to prevent dust or other contaminants from sticking to the surface.