

PW Panel Wipe



PRODUCT DESCRIPTION:

Gtechniq Panel Wipe is designed to remove all polish residues so that ultra durable chemically bonding coatings such as C1 Crystal Lacquer and EXOv2 can form the maximum amount of bonds with your vehicle's paintwork. PW is a blend of pure alcohols and aromatic solvents formulated specifically to give adequate working time to remove and dissolve polish residues and then flash off to leave a 100% decontaminated surface.

OTHER EQUIPMENT/PRODUCTS RECOMMENDED FOR USE:

- Clean, high quality microfiber towels

PRIOR TO USE:

- All surface cleaning and correcting should be finished and dust from paint correction should be mostly removed.

RECOMMENDED USE:

- PW Panel Wipe should be used to prep all surfaces of the vehicle before coatings are applied.
- Best when cut 1/1 with distilled water

APPLICATION INSTRUCTIONS:

-PAINT: Once all your paint correction has been finished and the dust has been removed, take two high quality microfiber towels to clean the painted surfaces with Panel Wipe. Lightly mist ONE of the microfiber towels with Panel Wipe and use liberally on the section you are working on. Work on only one section at a time with each section being no larger than half of a panel. Spread Panel Wipe around the section you are working on with the lightly misted microfiber towel. Take the second, dry, microfiber towel and lightly wipe off the section you are working on until the Panel Wipe flashes. All surfaces should be gone over twice to ensure complete removal of waxes/silicones/oily residue.

- GLASS: After glass has been polished with G4 Glass Nano Polish, grab a clean microfiber towel and prep the glass surface for G1 ClearVision Smart Glass by following the same method described above and working one window at a time.

-RIMS: Working on one rim at a time, follow instructions for paint.

-TIRES: If you plan on using Panel Wipe on tires, make sure you do it BEFORE you coat the rims as the Panel Wipe will hinder the coating's effectiveness. Spray liberally on tires and wipe off.

-PLASTICS: Using two clean microfiber towels, spray one towel liberally with Panel Wipe, wipe across plastic/trim you are working on, wipe off with dry microfiber towel.