

hydrosilex

CERAMIC COATING FOR ALL SURFACES



PLEASE READ BEFORE USING!

Recommended Application Methods.

Beginner

Dry Application

1. Mist onto clean surface.
2. Immediately dry with a clean microfiber towel.
3. Buff with an additional clean microfiber towel.

Expert

Wet Application

1. Mist onto clean wet surface.
2. Immediately rinse off & dry with a clean microfiber towel.
3. Buff with an additional clean microfiber towel.

Expert

Foam Cannon application

1. Spray entire clean surface
2. Rinse off with water & dry with a clean microfiber towel.
3. Buff with an additional clean microfiber towel.

NOTE* When drying the vehicle make sure you use microfiber towels and if residue is present wipe until gone. Use a rapid waving motion until achieved.

Installation Reminders

1. Spray and rinse one panel at a time.
2. Do not allow Recharge to dry on the surface. Rinse immediately with a garden hose or high-pressure rinse.
3. Do not spray product excessively onto surface. 3 to 6 ounces per vehicle depending on size of the vehicle.
4. Wipe windows and wipers clean from any overspray.
5. Use clean microfiber towels only!
6. Do not apply in direct sunlight, strong winds or extreme heat.

By not following these directions precisely it can result in a haze or spots on the surface.