



408.891	PE 8-4 180 120V Spare Parts List
FLEX ITEM#	Part Name
257,571	Adjusting Washer
159,204	O Ring
159,271	Needle Bearing
211,796	Screw
411,728	Gear Case
203,858	Tapping Screw
250,266	O Ring
250,589	Compression Spring
250,265	Locking Assembly
375,764	Gear Case
258,012	O Ring
376,124	Middle Cover
315,028	O Ring
254,442	Ball Bearing
358,150	Bearing Retainer
336,645	Dust Cover
254,443	Ball Bearing
379,166	Magnet Ring ASSY
336,653	Bearing Holder
336,661	Fan Baffle
336,823	Tapping Screw
405,825	Stator
386,391	Front Housing
336,718	Brush Support
336,831	Hexagon Lobuar Screw
336,769	Switch
336,807	Carbon Brush with safety fuse
336,858	Spring
358,304	Sensitive Resistor Assembly
407,739	PCB Assembly
336,742	Cord Anchorage
358,363	Hexagon Socket Screw
359,432	Connector
336,777	Spring
358,347	Switch Actuator
358,371	Switch Button
198,633	Handle
336,750	Cord Guard
407,755	Rear Housing maroon
329,797	Hexagon Lobuar Screw
407,771	Power Cord & Plug
405.795	Gear Shaft Assembly
382.698	Repair-Set Armature+Pinion PE 8-4 - 5/8"